



DIVEMASTER 3-PACK

HERO9 Black

PROTECTIVE HOUSING

VERSION 1.0



What's Included

DIVEMASTER Kit [H9-1016]

*Red | Magenta | Snorkel | Hard Shell Storage Case
Security Tether*

Choosing Your Filter

Step 1

We suggest that all installation steps be completed above water with all gear clean and dry. The Hero 9 DiveMaster Filter Kit is only compatible with the HERO9 + Protective Housing.

Step 2

The HERO9 DiveMaster Kit includes three different filters to color correct your footage in any water condition. To select the most appropriate filter for your diving situation we suggest the following use cases (*Filter Chart on next page*).

Choosing Your Filter (Continued)



RED	Performs best in blue waters from depths of 15-75 feet
MAGENTA	Performs best green waters from depths of 15-75 feet
SNORKEL	Performs best in shallow waters from depths of 2 to 20 feet

Attaching Security Tether

Step 1

Once you've selected the filter best for your shoot, attach one of the provided tether.

Step 2

Slide one end of the tether through one of the holes located on the corner of the filter.

Step 3

Return the same end of the tether back out of the secondary hole in the same corner.

Step 4

Feed through remaining loop of the tether outside of the filter.

Step 5

Pull tight and double-check a secure hold.

Tethering to Mount

Step 1

Before attaching your GoPro to any grip/handle/mount, loop the free end of the tether string through the housing's mounting fingers.

Step 2

Attach the GoPro as usual, screwing the thumbscrew through the mounting fingers. This will keep your filter safe in the event that you remove it accidentally or intentionally on your dive.

Filter Installation

Pro Tip

HERO9 Dive Filters are designed specifically to integrate with the slot on the lens portion of the HERO9 Protective Housing. They are best installed by sliding horizontally from right to left when facing the camera.

Step 1

With the open side of the filter, align the bottom edge of the filter with the front face of the Protective Housing, centered with the lens.

Step 2

Slide the filter from right to left onto the Protective Housing lens. You will feel some light resistance as the filter interfaces with the slot.

Filter Installation (Continued)

Step 3

Once the filter reaches a hard stop the integrated springarms will hold the filter securely to the Protective Housing.

Step 4

Once secure you can start capturing vibrant colors with optical clarity.

Filter Removal

Step 1

To remove, grip the filter by the textured sides and slide the filter in the direction opposite of the opening. If you're facing the camera's lens, this will be from left to right.

Filter Care

Step 1

After use in salt water we recommended to rinse the filter with warm water and dry thoroughly before placing in storage. This will protect the filter from the chance of corrosion over time.

Still unsure about your DiveMaster filter installation, check out the getting started video located on our YouTube Channel or FAQ page.

GETTING STARTED VIDEO

More Info

Tutorials

For additional help be sure to visit our YouTube page:

[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)

for tutorials and more.

Questions

Contact us at anytime via our website, or shoot us an email. We're happy to help.

polarpro.com | 949.220.9395

support@polarpro.com