

Brand	Model	Cable Name
canon	1000D	1C Shutter Link Cable
canon	10D	3C Shutter Link Cable
canon	1100D	1C Shutter Link Cable
canon	1200D	1C Shutter Link Cable
canon	1300D	1C Shutter Link Cable
canon	1D	3C Shutter Link Cable
canon	1D II	3C Shutter Link Cable
canon	1D MK II	3C Shutter Link Cable
canon	1D MK III	3C Shutter Link Cable
canon	1D MK IV	3C Shutter Link Cable
canon	1DC	3C Shutter Link Cable
canon	1DS	3C Shutter Link Cable
canon	1DS MK II	3C Shutter Link Cable
canon	1DS MK II N	3C Shutter Link Cable
canon	1DX	3C Shutter Link Cable
canon	1DX MK II	3C Shutter Link Cable
canon	20D	3C Shutter Link Cable
canon	300D	1C Shutter Link Cable
canon	350D	1C Shutter Link Cable
canon	400D	1C Shutter Link Cable
canon	450D	1C Shutter Link Cable
canon	500D	1C Shutter Link Cable
canon	550D	1C Shutter Link Cable
canon	5D MK II	3C Shutter Link Cable
canon	5D MK III	3C Shutter Link Cable
canon	5D MK IV	3C Shutter Link Cable
canon	5DSR	3C Shutter Link Cable
canon	600D	1C Shutter Link Cable
canon	650D	1C Shutter Link Cable
canon	6D	3C Shutter Link Cable
canon	6D MK II	3C Shutter Link Cable
canon	700D	1C Shutter Link Cable
canon	750D	1C Shutter Link Cable
canon	760D	1C Shutter Link Cable
canon	7D	3C Shutter Link Cable
canon	7D MK II	3C Shutter Link Cable
canon	800D	1C Shutter Link Cable
canon	80D	1C Shutter Link Cable
canon	D30	1C Shutter Link Cable
canon	D60	3C Shutter Link Cable
canon	F	1C Shutter Link Cable
canon	G11	1C Shutter Link Cable
canon	G12	1C Shutter Link Cable
canon	G15	1C Shutter Link Cable
canon	G5X	1C Shutter Link Cable
canon	M5	1C Shutter Link Cable
canon	N	1C Shutter Link Cable

canon	SL1	1C Shutter Link Cable
canon	SX50 HS	1C Shutter Link Cable
canon	T1i	1C Shutter Link Cable
canon	G10	1C Shutter Link Cable
canon	T2i	1C Shutter Link Cable
canon	T3	1C Shutter Link Cable
canon	T3i	1C Shutter Link Cable
canon	T4i	1C Shutter Link Cable
canon	T5i	1C Shutter Link Cable
canon	T6s	1C Shutter Link Cable
canon	T7i	1C Shutter Link Cable
canon	X2	1C Shutter Link Cable
canon	X3	1C Shutter Link Cable
canon	X4	1C Shutter Link Cable
canon	X5	1C Shutter Link Cable
canon	X50	1C Shutter Link Cable
canon	X6	1C Shutter Link Cable
canon	X9	1C Shutter Link Cable
canon	XS	1C Shutter Link Cable
canon	Xsi	1C Shutter Link Cable
canon	XT	1C Shutter Link Cable
canon	Xti	1C Shutter Link Cable
canon	R	1C Shutter Link Cable
fuji	X30	1F Shutter Link Cable
fuji	X100F	1F Shutter Link Cable
fuji	X100T	1F Shutter Link Cable
fuji	X70	1F Shutter Link Cable
fuji	XA1	1F Shutter Link Cable
fuji	XA2	1F Shutter Link Cable
fuji	XA3	1F Shutter Link Cable
fuji	XE1	1F Shutter Link Cable
fuji	XE2	1F Shutter Link Cable
fuji	XE2S	1F Shutter Link Cable
fuji	XM1	1F Shutter Link Cable
fuji	XPRO1	1F Shutter Link Cable
fuji	XPRO2	1F Shutter Link Cable
fuji	XQ1	1F Shutter Link Cable
fuji	XQ2	1F Shutter Link Cable
fuji	XT1	1F Shutter Link Cable
fuji	XT10	1F Shutter Link Cable
fuji	XT2	1F Shutter Link Cable
fuji	XT20	1F Shutter Link Cable
fuji	XH1	1F Shutter Link Cable
fuji	XT100	1F Shutter Link Cable
fuji	X70	1F Shutter Link Cable
fuji	XA1	1F Shutter Link Cable
fuji	XA2	1F Shutter Link Cable
fuji	XA3	1F Shutter Link Cable

fuji	XF10	1F Shutter Link Cable
fuji	XM1	1F Shutter Link Cable
fuji	XPRO1	1F Shutter Link Cable
fuji	XQ1	1F Shutter Link Cable
fuji	XQ2	1F Shutter Link Cable
fuji	XT3	1C Shutter Link Cable
leica	V-Lux4	1P Shutter Link Cable
leica	V-Lux1114	1P Shutter Link Cable
leica	DigiLux3	1P Shutter Link Cable
leica	DigiLux2	1P Shutter Link Cable
leica	V-Lux1	1P Shutter Link Cable
leica	V-Lux2	1P Shutter Link Cable
leica	V-Lux3	1P Shutter Link Cable
minolta	DiIMAGE-5	1S Shutter Link Cable
minolta	DiIMAGE-7	1S Shutter Link Cable
minolta	DiIMAGE-7Hi	1S Shutter Link Cable
minolta	DiIMAGE-7i	1S Shutter Link Cable
minolta	DiIMAGE-A1	1S Shutter Link Cable
minolta	DiIMAGE-A2	1S Shutter Link Cable
minolta	DiIMAGE-A200	1S Shutter Link Cable
minolta	Dynax-3	1S Shutter Link Cable
minolta	Dynax-4	1S Shutter Link Cable
minolta	Dynax-5000	1S Shutter Link Cable
minolta	Dynax-500si	1S Shutter Link Cable
minolta	Dynax-505si	1S Shutter Link Cable
minolta	Dynax-5D	1S Shutter Link Cable
minolta	Dynax-7	1S Shutter Link Cable
minolta	Dynax-7000	1S Shutter Link Cable
minolta	Dynax-7D	1S Shutter Link Cable
minolta	Dynax-9	1S Shutter Link Cable
minolta	Dynax-9000	1S Shutter Link Cable
minolta	Dynax-Sweets	1S Shutter Link Cable
minolta	Maxxum-4	1S Shutter Link Cable
minolta	Maxxum-5000	1S Shutter Link Cable
minolta	Maxxum-500si	1S Shutter Link Cable
minolta	Maxxum-505si	1S Shutter Link Cable
minolta	Maxxum-5D	1S Shutter Link Cable
minolta	Maxxum-600si	1S Shutter Link Cable
minolta	Maxxum-7	1S Shutter Link Cable
minolta	Maxxum-7000	1S Shutter Link Cable
minolta	Maxxum-700si	1S Shutter Link Cable
minolta	Maxxum-7D	1S Shutter Link Cable
nikon	P7100	IR Shutter Link Cable
nikon	P7700	3N Shutter Link Cable
nikon	P7800	3N Shutter Link Cable
nikon	D3000	IR Shutter Link Cable
nikon	D300S	1N Shutter Link Cable
nikon	D3100	3N Shutter Link Cable

nikon	D3200	3N Shutter Link Cable
nikon	D3300	3N Shutter Link Cable
nikon	D3400	IR Shutter Link Cable
nikon	D3S	1N Shutter Link Cable
nikon	D3X	1N Shutter Link Cable
nikon	D4	1N Shutter Link Cable
nikon	D4S	1N Shutter Link Cable
nikon	D5	1N Shutter Link Cable
nikon	D500	1N Shutter Link Cable
nikon	D5000	IR Shutter Link Cable
nikon	D5100	IR Shutter Link Cable
nikon	D5200	3N Shutter Link Cable
nikon	D5300	3N Shutter Link Cable
nikon	D5500	3N Shutter Link Cable
nikon	D5600	3N Shutter Link Cable
nikon	D5600	3N Shutter Link Cable
nikon	D600	3N Shutter Link Cable
nikon	D610	3N Shutter Link Cable
nikon	D7000	IR Shutter Link Cable
nikon	D7100	3N Shutter Link Cable
nikon	D7200	3N Shutter Link Cable
nikon	D750	3N Shutter Link Cable
nikon	D7500	3N Shutter Link Cable
nikon	D800	1N Shutter Link Cable
nikon	D810	1N Shutter Link Cable
nikon	D810A	1N Shutter Link Cable
nikon	D850	1N Shutter Link Cable
nikon	D90	3N Shutter Link Cable
nikon	D70S	2N Shutter Link Cable
nikon	D80	2N Shutter Link Cable
nikon	Df	3N Shutter Link Cable
nikon	D300	1N Shutter Link Cable
nikon	D70S	2N Shutter Link Cable
nikon	D80	2N Shutter Link Cable
nikon	Z6	3N Shutter Link Cable
nikon	Z7	3N Shutter Link Cable
olympus	E-100	3L Shutter Link Cable
olympus	E-30	3L Shutter Link Cable
olympus	E-330	3L Shutter Link Cable
olympus	E-400	3L Shutter Link Cable
olympus	E-400	3L Shutter Link Cable
olympus	E-410	3L Shutter Link Cable
olympus	E-420	3L Shutter Link Cable
olympus	E-450	3L Shutter Link Cable
olympus	E-500	3L Shutter Link Cable
olympus	E-510	3L Shutter Link Cable
olympus	E-600	3L Shutter Link Cable
olympus	E-620	3L Shutter Link Cable

olympus	EM1	3L Shutter Link Cable
olympus	EM1 Mk II	1C Shutter Link Cable
olympus	EM10	3L Shutter Link Cable
olympus	EM10 II	3L Shutter Link Cable
olympus	EM10 III	3L Shutter Link Cable
olympus	EM5	3L Shutter Link Cable
olympus	EM5 II	3L Shutter Link Cable
olympus	PEN-EP1	3L Shutter Link Cable
olympus	PEN-E-P2	3L Shutter Link Cable
olympus	PEN-EP3	3L Shutter Link Cable
olympus	PEN-EP5	3L Shutter Link Cable
olympus	PEN-EPL2	3L Shutter Link Cable
olympus	PEN-EPL3	3L Shutter Link Cable
olympus	PEN-EPL5	3L Shutter Link Cable
olympus	PEN-EPL7	3L Shutter Link Cable
olympus	PEN-EPL8	3L Shutter Link Cable
olympus	PEN-EPM1	3L Shutter Link Cable
olympus	PEN-EPM2	3L Shutter Link Cable
olympus	SP550	3L Shutter Link Cable
olympus	SP560	3L Shutter Link Cable
olympus	SP570	3L Shutter Link Cable
olympus	XZ1	3L Shutter Link Cable
olympus	XZ2	3L Shutter Link Cable
olympus	XZ2 HIS	3L Shutter Link Cable
olympus	EM1X	1C Shutter Link Cable
panasonic	DC-GH5	1P Shutter Link Cable
panasonic	DC-GH5S	1P Shutter Link Cable
panasonic	DMC-FZ1000GN	1P Shutter Link Cable
panasonic	DMC-FZ2500	1P Shutter Link Cable
panasonic	DMC-FZ300GN	1P Shutter Link Cable
panasonic	DMC-G7GN	1P Shutter Link Cable
panasonic	DMC-G7HGN	1P Shutter Link Cable
panasonic	DMC-G7KGN	1P Shutter Link Cable
panasonic	DMC-G7WGN	1P Shutter Link Cable
panasonic	DMC-G85	1P Shutter Link Cable
panasonic	DMC-GH4	1P Shutter Link Cable
panasonic	DMC-GH4A	1P Shutter Link Cable
panasonic	DMC-GX8GN	1P Shutter Link Cable
panasonic	DC-GH5S	1P Shutter Link Cable
pentax	645D	1C Shutter Link Cable
pentax	645Z	1C Shutter Link Cable
pentax	DL2	1C Shutter Link Cable
pentax	DS2	1C Shutter Link Cable
pentax	DS2	1C Shutter Link Cable
pentax	DS2	1C Shutter Link Cable
pentax	K1	1C Shutter Link Cable
pentax	K1 II	1C Shutter Link Cable
pentax	K10 Grand Prix	1C Shutter Link Cable

pentax	K100D	1C Shutter Link Cable
pentax	K100D Super	1C Shutter Link Cable
pentax	K10D	1C Shutter Link Cable
pentax	K110D	1C Shutter Link Cable
pentax	K200D	1C Shutter Link Cable
pentax	K20D	1C Shutter Link Cable
pentax	K-3	1C Shutter Link Cable
pentax	K-3 II	1C Shutter Link Cable
pentax	K-30	1C Shutter Link Cable
pentax	K-5	1C Shutter Link Cable
pentax	K-5 II	1C Shutter Link Cable
pentax	K-5 IIs	1C Shutter Link Cable
pentax	K-50	1C Shutter Link Cable
pentax	K-500	1C Shutter Link Cable
pentax	K-7	1C Shutter Link Cable
pentax	KP	1C Shutter Link Cable
pentax	K-M	1C Shutter Link Cable
pentax	MZ-6	1C Shutter Link Cable
pentax	MZ-L	1C Shutter Link Cable
pentax	ZX-L	1C Shutter Link Cable
samsung	GX10	1C Shutter Link Cable
samsung	GX1L	1C Shutter Link Cable
samsung	GX1S Shutter Link Cable	1C Shutter Link Cable
samsung	GX20	1C Shutter Link Cable
samsung	NX10	1C Shutter Link Cable
samsung	NX100	1C Shutter Link Cable
samsung	NX11	1C Shutter Link Cable
samsung	NX5	1C Shutter Link Cable
sony	a7	2S Shutter Link Cable
sony	a9	2S Shutter Link Cable
sony	a33	1S Shutter Link Cable
sony	a35	1S Shutter Link Cable
sony	a37	1S Shutter Link Cable
sony	a55	1S Shutter Link Cable
sony	a57	1S Shutter Link Cable
sony	a65	1S Shutter Link Cable
sony	a68	2S Shutter Link Cable
sony	a77	1S Shutter Link Cable
sony	a99	1S Shutter Link Cable
sony	a100	1S Shutter Link Cable
sony	a200	1S Shutter Link Cable
sony	a300	1S Shutter Link Cable
sony	a350	1S Shutter Link Cable
sony	a500	1S Shutter Link Cable
sony	a550	1S Shutter Link Cable
sony	a560	1S Shutter Link Cable
sony	a580	1S Shutter Link Cable
sony	a700	1S Shutter Link Cable

sony	a850	1S Shutter Link Cable
sony	a900	1S Shutter Link Cable
sony	a5000	2S Shutter Link Cable
sony	a5100	2S Shutter Link Cable
sony	a6000	2S Shutter Link Cable
sony	a6300	2S Shutter Link Cable
sony	a6500	2S Shutter Link Cable
sony	a77II	2S Shutter Link Cable
sony	a7II	2S Shutter Link Cable
sony	a7R	2S Shutter Link Cable
sony	a7RII	2S Shutter Link Cable
sony	a7RIII	2S Shutter Link Cable
sony	a7III	2S Shutter Link Cable
sony	a7S	2S Shutter Link Cable
sony	a7SII	2S Shutter Link Cable
sony	a99II	2S Shutter Link Cable
sony	HX 300	2S Shutter Link Cable
sony	HX 400	2S Shutter Link Cable
sony	HX 400V	2S Shutter Link Cable
sony	HX 50V	2S Shutter Link Cable
sony	HX 90V	2S Shutter Link Cable
sony	HX300	2S Shutter Link Cable
sony	RX 10	2S Shutter Link Cable
sony	RX 10 II	2S Shutter Link Cable
sony	RX 10 III	2S Shutter Link Cable
sony	RX 100 Mark II	2S Shutter Link Cable
sony	RX 100 Mark IV	2S Shutter Link Cable
sony	RX 100 Mark V	2S Shutter Link Cable
sony	RX 100 Mark VI	2S Shutter Link Cable
sony	RX 1RII	2S Shutter Link Cable
sony	WX500	2S Shutter Link Cable
sony	a7RIII	2S Shutter Link Cable
sony	a7III	2S Shutter Link Cable
sony	RX 100 Mark VI	2S Shutter Link Cable
sony	RX 10 IV	2S Shutter Link Cable

as of 01/04/2019