


UNIVERSAL BALL HEAD ADAPTER INSTRUCTIONS

remove PD Ball Head



- 1 Loosen Ball Head ring and tilt until hole is visible on top, and unscrew using 4mm hex wrench.



- 2 Pull up to remove the Compact Ball Head.

install Universal Head Adapter



- 1 Screw adapter in using 4mm hex wrench to tighten to center column.

install third party tripod head



- 1 Screw in 3rd party tripod head.



- 2 Raise stabilizing screws to prevent head from twisting.