

Camera Pouch – NG E2 2350

The National Geographic Camera Pouch is the simple, handy solution for all your compact camera needs! Perfect for protecting your compact camera, point-and-shoot film camera, action camera, 360 camera, or assorted small accessories.

With multiple ways to carry the pouch, you can store it within a larger bag to neatly compartmentalise your gear, use the integrated belt loop for fast hip access, or attach the included neck strap for easy shooting no matter your outfit choice!

Featuring a separate front pocket for memory cards or other slim accessories, you'll have everything on hand, and be travelling light at the same time.



**Sustainable
hangtag with
cotton thread**

PERFECT FOR:

Compact
Camera



Action
Camera



360
Camera



Accessories



**Integrated
belt loop**



**Perfect size for
action cameras**



**Front pocket for
memory cards**