

Shoulder Bag Medium – NG E2 2370

The National Geographic Shoulder Bag Medium is designed for DSLRs or mirrorless cameras, with 2 additional lenses (depending on size), accessories, batteries or memory cards. Adjustable, foam dividers enable you to customise the inside of the bag to fit your needs.

With sturdy zip and buckle locking for extra security you can carry your gear with confidence. The adjustable shoulder strap and handy grab handle never holds you back from taking the National Geographic Shoulder Bag with you on your travels!

Features interior padded tablet sleeve for further flexibility, keeping everything in one place when travelling or on the go.

Ultra-lightweight and compact, this shoulder bag snugly fits your equipment, whilst displaying the signature National Geographic logo detail.



Adjustable,
foam dividers



Padded tablet
sleeve



Buckle and
zip fastening



Sustainable
hangtag with
cotton thread

PERFECT FOR:

Medium
DSLR

Entry
DSLR

Pro CSC

CSC

Foldable
Drone

Tablet

