

# CRANE-M 3S Camera Compatibility List

ZHIYUN

Update on May 08, 2023 (Firmware version V1.72)

V1.00

Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7M2	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7R2	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7R2	FE 40mm F2.5 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7S2	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7S2	Vario-Tessar T* FE 24-70mm F4 ZA OSS	Standard quick release plate provided	√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7M3	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7M4	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7M4	FE 40mm F2.5 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7R3	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark		
				Horizontal	Vertical	Horizontal	Vertical				
Sony	α7S3	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap		
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap		
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap		
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap		
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap		
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap		
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap		
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap		
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap		
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap		
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap		
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap		
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap		
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap		
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap		
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap		
		α7R4		FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
	FE 24mm F2.8 G		√	-		-	-	-	No need to remove eyepiece cap		
	FE 24mm F1.4 GM		√	-		-	-	-	Need to remove eyepiece cap		
	FE 28mm F2		√	-		-	-	-	No need to remove eyepiece cap		
	FE 35mm F1.8		√	-		-	-	-	Need to remove eyepiece cap		
	Sonnar T* FE 35mm F2.8 ZA		√	-		-	-	-	No need to remove eyepiece cap		
	FE 40mm F2.5 G		√	-		-	-	-	No need to remove eyepiece cap		
	Sigma 45mm f/2.8 DG DN		√	-		-	-	-	No need to remove eyepiece cap		



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7R4	FE 50mm F1.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7R5	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	FX3	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	Need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α7C	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α7C	FE 50mm F1.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	ZV-E1	FE 20mm F1.8 G	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F1.4 GM		√	-	-	-	-	Need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap





Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	ZV-E1	FE 28-60mm F4-5.6	Standard quick release plate provided	√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at 24-50mm, need to remove eyepiece cap
	α6600	FE 14mm F1.8 GM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.8		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α6500	Sonnar® T* FE 55mm F1.8 ZA	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, No need to remove eyepiece cap
		FE 14mm F1.8 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.8		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α6500	Sonnar® T* FE 55mm F1.8 ZA	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
	α6400	FE 14mm F1.8 GM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap

Online M4/3 camera compatibility list									
Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α6400	FE 50mm F2.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
	α6300	FE 14mm F1.8 GM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α6300	FE 50mm F2.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, No need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, No need to remove eyepiece cap
	α6100	FE 14mm F1.8 GM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	α6100	FE 50mm F2.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, No need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, No need to remove eyepiece cap
	ZV-E10	FE 14mm F1.8 GM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		FE 20mm F1.8 G		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* E 24mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 24 mm F1.4 GM		√	-	-	-	-	No need to remove eyepiece cap
		FE 24mm F2.8 G		√	-	-	-	-	No need to remove eyepiece cap
		FE 28mm F2		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 30mm f/1.4 DC DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		Sonnar T* FE 35mm F2.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 40mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap
		Sigma 45mm f/2.8 DG DN		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		FE 50mm F2.5 G		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Sony	ZV-E10	FE 50mm F2.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Sonnar® T* FE 55mm F1.8 ZA		√	-	-	-	-	No need to remove eyepiece cap
		FE 85mm f/1.8		√	-	-	-	-	No need to remove eyepiece cap
		E 10–18mm F4 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE PZ 16-35mm F4 G		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-60mm F4-5.6		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Sigma 28-70mm f/2.8 DG DN		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		FE 28-70mm F3.5-5.6 OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* E 16-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Vario-Tessar T* FE 24-70mm F4 ZA OSS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Tamron 28-75mm F2.8 Di III RXD		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
		Tamron 28-75mm F/2.8 Di III VXD G2		√	-	-	-	-	Can be balanced at 28-35mm, no need to remove eyepiece cap
	DSC- RX100M5A	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
	DSC-RX100M5	Comes with the lens		√	-	-	-	-	Should be powered on to balance
	DSC-RX100M6	Comes with the lens		√	-	-	-	-	Should be powered on to balance
	DSC-RX100M7	Comes with the lens		√	-	-	-	-	Should be powered on to balance
	DSC-WX350	Comes with the lens		√	-	-	-	-	Should be powered on to balance
	DSC-HX90	Comes with the lens		√	-	-	-	-	Should be powered on to balance
	ZV-1	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS R	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS R5	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS R6	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap





Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS R6 Mark II	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS R7	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS R8	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS R10	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS R50	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS RP	RF 15-30mm f/4.5-6.3 IS STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		RF 16mm F2.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-105mm F4-7.1 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24mm f/1.8 Macro IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 35mm F1.8 MACRO IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 50mm F1.8 STM		√	-	-	-	-	Do not remove eyepiece cap
		RF-S 18-45mm f/4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		RF 24-50mm F4.5-6.3 IS STM		√	-	-	-	-	Do not remove eyepiece cap
	EOS M50	EF-M 22mm f/2 STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		EF-M 28mm f/3.5 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		EF-M 32mm f/1.4 STM		√	-	-	-	-	Do not remove eyepiece cap
		EF-M 11-22mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 15-45mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 18-150mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at 18-50mm, do not remove eyepiece cap
	M50 Mark II	EF-M 22mm f/2 STM	Standard quick release plate provided	√	-	-	-	-	Do not remove eyepiece cap
		EF-M 28mm f/3.5 IS STM		√	-	-	-	-	Do not remove eyepiece cap
		EF-M 32mm f/1.4 STM		√	-	-	-	-	Do not remove eyepiece cap
		EF-M 11-22mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 15-45mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, do not remove eyepiece cap
		EF-M 18-150mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at 18-50mm, do not remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS M6	EF-M 22mm f/2 STM	Standard quick release plate provided	√	-	-	-	-	-
		EF-M 28mm f/3.5 IS STM		√	-	-	-	-	-
		EF-M 32mm f/1.4 STM		√	-	-	-	-	-
		EF-M 11-22mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 15-45mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 18-150mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length
	EOS M6 Mark II	EF-M 22mm f/2 STM	Standard quick release plate provided	√	-	-	-	-	-
		EF-M 28mm f/3.5 IS STM		√	-	-	-	-	-
		EF-M 32mm f/1.4 STM		√	-	-	-	-	-
		EF-M 11-22mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 15-45mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length
		EF-M 18-150mm f/3.5-6.3 IS STM		√	-	-	-	-	Can be balanced at any focal length
	EOS 200D	EF 24mm f/2.8 IS USM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		EF-S 24mm f/2.8 STM		√	-	-	-	-	No need to remove eyepiece cap
		EF 35mm f/2 IS USM		√	-	-	-	-	No need to remove eyepiece cap
		EF-S 35mm f/2.8 IS STM MC		√	-	-	-	-	No need to remove eyepiece cap
		EF 50mm f/1.4 USM		√	-	-	-	-	No need to remove eyepiece cap
		EF 50mm f/1.8 STM		√	-	-	-	-	No need to remove eyepiece cap
		EF-S 10-18mm f/4.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		EF-S 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		EF-S 18-55mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Canon	EOS 200D Mark II	EF 24mm f/2.8 IS USM	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		EF-S 24mm f/2.8 STM		√	-	-	-	-	No need to remove eyepiece cap
		EF 35mm f/2 IS USM		√	-	-	-	-	No need to remove eyepiece cap
		EF-S 35mm f/2.8 IS STM MC		√	-	-	-	-	No need to remove eyepiece cap
		EF 50mm f/1.4 USM		√	-	-	-	-	No need to remove eyepiece cap
		EF 50mm f/1.8 STM		√	-	-	-	-	No need to remove eyepiece cap
		EF-S 10-18mm f/4.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		EF-S 18-55mm f/3.5-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		EF-S 18-55mm f/4-5.6 IS STM		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	PowerShot G1X Mark II	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
	PowerShot G7X Mark III	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
	PowerShot SX720 HS	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
Nikon	Z30	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z DX 18-140mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at 18-50mm, No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Nikon	Z50	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	Z5	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	Z6	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Nikon	Z6 II	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	Z7	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	Z7 II	NIKKOR Z 28mm f/2.8 (SE)	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 35mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Nikon	Zfc	NIKKOR Z 35mm f/1.8S	Standard quick release plate provided	√	-	-	-	-	-
		NIKKOR Z 28mm f/2.8 (SE)		√	-	-	-	-	-
		NIKKOR Z 40mm f/2		√	-	-	-	-	-
		NIKKOR Z 50mm f/1.8S		√	-	-	-	-	-
		NIKKOR Z MC 50mm f/2.8		√	-	-	-	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z 24-50mm f/4-6.3		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		NIKKOR Z DX 18-140mm f/3.5-6.3 VR		√	-	-	-	-	Can be balanced at 18-50mm, No need to remove eyepiece cap
FUJIFILM	X-T20	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap





Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-T20	XF56mmF1.2 R APD	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
	X-A7	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-A7	XF10-24mmF4 R OIS WR	Standard quick release plate provided	√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
	X-T2	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-T2	XC16-50mmF3.5-5.6 OIS II	Standard quick release plate provided	√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
	X-T3	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-T4	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-T5	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-H2s	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-S10	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
FUJIFILM	X-T30	XF14mmF2.8 R	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF1.4 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF16mmF2.8 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XF18mmF2 R		√	-	-	-	-	No need to remove eyepiece cap
		XF23mmF1.4 R		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF1.4 R LM WR		√	-	-	-	-	Need to remove eyepiece cap
		XF23mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF27mmF2.8		√	-	-	-	-	No need to remove eyepiece cap
		XF30mmF2.8 R LM WR Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF33mmF1.4 R LM WR		√	-	-	-	-	No need to remove eyepiece cap
		XC35mmF2		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/1.4 R		√	-	-	-	-	No need to remove eyepiece cap
		XF 35mm f/2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF50mmF2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R WR		√	-	-	-	-	No need to remove eyepiece cap
		XF56mmF1.2 R APD		√	-	-	-	-	No need to remove eyepiece cap
		XF60mmF2.4 R Macro		√	-	-	-	-	No need to remove eyepiece cap
		XF10-24mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC 15-45mm f/3.5-5.6 OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XC16-50mmF3.5-5.6 OIS II		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF 18-55mm f/2.8-4 R OIS		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap
		XF16-80mmF4 R OIS WR		√	-	-	-	-	Can be balanced at any focal length, need to remove eyepiece cap





Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Panasonic	DC-G100	LEICA DG SUMMILUX 15mm f/1.7 ASPH	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Lumix G 25mm f/1.4		√	-	-	-	-	No need to remove eyepiece cap
		Lumix G 25mm f/1.7		√	-	-	-	-	No need to remove eyepiece cap
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		12-32 0.2m/0.66ft		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
	DMC-GH4	LEICA DG MACRO 45mm f/2.8 OIS	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG SUMMILUX 15mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 14mm / F2.5 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 20mm / F1.7 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 25mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
	DMC-GH5	LEICA DG MACRO 45mm f/2.8 OIS	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG SUMMILUX 15mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Panasonic	DMC-GH5	Panasonic Leica DG Summilux 12mm f/1.4 ASPH	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 14mm / F2.5 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 20mm / F1.7 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 25mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
	DMC-GH5S	LEICA DG MACRO 45mm f/2.8 OIS	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG SUMMILUX 15mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 14mm / F2.5 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 20mm / F1.7 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 25mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
	DMC-GH6	LEICA DG MACRO 45mm f/2.8 OIS	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG SUMMILUX 15mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Panasonic	DMC-GH6	Panasonic Leica DG Summilux 25mm f/1.4 II ASPH	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 14mm / F2.5 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 20mm / F1.7 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 25mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
	DMC-G9	LEICA DG MACRO 45mm f/2.8 OIS	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG SUMMILUX 15mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS		√	-	-	-	-	Can be balanced at any focal length, no need to remove eyepiece cap
		Panasonic Leica DG Summilux 12mm f/1.4 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Leica DG Summilux 25mm f/1.4 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 14mm / F2.5 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic LUMIX G 20mm / F1.7 II ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 25mm f/1.7 ASPH		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G 42.5mm f/1.7 ASPH. POWER O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
		Panasonic Lumix G Macro 30mm f/2.8 ASPH. MEGA O.I.S.		√	-	-	-	-	No need to remove eyepiece cap
	DMC-S5	LUMIX S 18mm F1.8	Standard quick release plate provided	√	-	-	-	-	No need to remove eyepiece cap
		LUMIX S 24mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		LUMIX S 35mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		LUMIX S 50mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		LUMIX S 85mm F1.8		√	-	-	-	-	No need to remove eyepiece cap
		LUMIX S 20-60 mm F3.5-5.6		√	-	-	-	-	No need to remove eyepiece cap



Camera Brand	Model	Lens Model	Mounting Status	Balance Adjustment		Camera Backing Base		Servo Zoom/ Focus Motor	Installation Remark
				Horizontal	Vertical	Horizontal	Vertical		
Panasonic	DMC-LX100M2	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
	DMC-LX10	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
	DMC-ZS110	Comes with the lens	Standard quick release plate provided	√	-	-	-	-	Should be powered on to balance
SIGMA	fp	45mm F2.8	Standard quick release plate provided	√	-	-	-	-	-